

HELP: 1-888-751-4086 or 1-866-894-0637 (fE)

GSPN

http://gspn3.samsungcsportal.com

PLUS ONE

http://my.plus1solutions.net/clientPortals/samsung

HOT TIPS

Power On Problems: (see page 2) Video Problems: (see pages 3,4) TIP: After replacing Main/Panel

picture is upside down.

Fix: Test Mode/Mirror Option/Toggle

FIRMWARE:

None at this time

SERVICE BULLETINS

NO BULLETINS AS OF 10/3/11

Verify Part Numbers Are Current

<u>Version</u>		
	<u>Parts No</u>	Short Description
ALL	BN44-00417A	Power PCB
		Function & IR PCB
ALL	BN96-16269B	
ALL	BN94-03986V	Main PCB
ALL	BN07-00800A	Panel
ALL	BN81-04462A	T-CON PCB
ALL	BN61-06027A	Stand Guide Neck
ALL	BN96-13963R	Rear Cover
ALL	BN96-13509F	Front Cover
ALL	BN96-12799A	Stand Guide
ALL	BBN9612799C	Stand Base
ALL	BN40-00140B	Tuner
ALL	BN96-12837A	Speaker
ALL	BN96-15047D	LVDS Cable
ALL	<u>3903-00467</u>	Power Cord
ALL	BN59-01006A	Remote
ALL	BN63-01798B	Cleaning Cloth



B5V

GND

GND

GND

B13V

B13V

B13V

GND

DET_5V

NC

NC

LED C

I-PWM

(ANA)


INVETER

E-PWM

(PWM)

NC

SW



Power On Sequence (approximate Voltages)

- Standby Voltages: CN802-4 (5V)
- Power On CN802-2 (0 3V)
- **Low Voltage Supplies On CN802-**3. 13,14,15,20,21,22 (Volts Listed on CN802)
- Back Light On CN802- (0-3V, delayed)
- 5. **Back Light Confirm CNI802- (FB1 & FB2)**
- Dimming Signal CN802-26 (1V-4V approx)

To Force Backlight On without Main Board:

- Remove Power Cord
- Remove CN802
- Plug Power Cord In.
- Backlight should be on immediately.

CITTOI					
1	IR	6	Key1		
2	GND	7	Key2		
3	A3.3V	8	GND		
4	LED	9	SDA		

Buzzer

10

Fast Track Troubleshooting Manual

TROUBLESHOOTING VIDEO PROBLEMS

1. Verify Video Operation

- a. Customer Picture Test (models available)
- b. "Display" (If display is OK source is suspected)
- C. Substitute with known good Source (external DVD or Signal Generator)

2. Using Test Patterns in Service Mode

- ENTER SERVICE MODE -

1. Select an active source signal. (HDMI preferred) Test Pattern may rely on signal source to appear.

Customer Remote

2. Power off


- 3. Mute, 182, Power

Service Remote

- 2. Power On
- **3.** Info, Factory


2010 Models with FRC 120Hz/240Hz


LCD Signal Path for Troubleshooting



4. Activate FRC Test Patterns & Verify.

T-Con Troubleshooting






SAMSUNG

Fast Track Troubleshooting Manual

ON SCREEN FAILURE EXAMPLES:



If Picture & Display errors Defective Main Board, LVDS, or T-CON




Green lines or a green screen defective main board, LVDS, or T-CON.



Original Image

Image on Screen

Pixelization can be caused by the main board but is more commonly a source error



Vertical or Horizontal Lines: Defective Panel likely but also T-CON, LVDS, or Main Board. Use Test Patterns in Factory Service Mode to determine error)

ALIGNMENTS:

Check/Set Option Bytes:

ote buttons in this order; POWER OFF-MUTE-1-9-2-POWER ON to turn the set on The set turns on and enters service mode. This may take approximately 20 seconds

US SAMSUNG

Initial SERVICE MODE DISPLAY State

Option Bytes

Factory Reset	THE THE
Туре	50HSnB4
Model	P8550
TUNER	ALPS
Region	US
DDR	SAMSUNG
Light Effect	Off
Inch	50"
Exhibition Mode	Off

SAMSUNG

Model Code	Front Color					
		Туре	Model	Tuner	Region	DDR
LN40C500F3FXZA	none	40A6Af1C	LC3500	Xugang	US	Etron

- 2. Check/Perform Firmware Upgrade for all repairs.
- 3. Perform reset in Service Mode & Plug and Play if Main board is replaced.

SPECIAL NOTES:

Inform customer of reset of all Settings if Main Board or Panel is replaced.